

TILE LAYING ADVICE



PREPARATION OF THE BASE

The base on which the laying will be effected, must be perfectly smooth, uniform and white.
A different colour damages the aesthetic look of the final result.



THE GLUEING OPERATION

White C2 glue, as per EN12004, must be used.
By using the smooth side of the trowel, the glue has to be spread out uniformly on the base (2 sq.m. approximately)
By using the jagged side of the trowel (2 or 3 mm.), comb the glue.



THE LAYING OF MOSAIC TILES

Adhere the sheet to the surface by pressing with a rubber trowel.
It is important to make sure that the distance between one sheet and another is the same as the one among the tesseras so that all the joints look alike.



GROUTING

Joints must be clean, dry and free from dust.
The remains of adhesive, after laying must be removed while it is still fresh.
Use grouting paste, RG type, as per EN 13888, spread it out with a rubber trowel.



CLEANING

Let it dry until the paste gets brightless, superficially, and then proceed to clean it with a sponge soaker in water.
Once it gets dry, remove it with a dry cloth.



NOTICE ON CROME SERIES

These pieces have been produced with a very thin layer of titanium. Unproper handling may cause irreversigle damages.

Follow the instructions that appear on the box.
The laying method is the same as the one for the rest of our products, with the following exceptions:
Use grouting materials exclusively based on superfine arid materials, (an average diametre of 12 microns)

Remove the remains of the grouting material, immediately, with an sponge soaker in water.
Do not use powdered detergent, steel wool or abrasives.

Remove the remains of the protecting film with a clean cloth, wet with alcohol or acetone, ending by cleaning with clear water.